



## Mounting instruction HOOK-ON SYSTEM

### For self-assembly you need further:

1. Hacksaw (to cut the mounting rail to the right width (on request we do this for you).
2. Screws or dowels to fasten the mounting rail on the door lintel.
3. a Phillips screwdriver (to turn the screws into the plastic plates).
4. a pair of scissors or utility knife (for cutting of each strip)

- 
- Use 30mm long screws to mount the stainless steel rail before or under the lintel.
  - Insert the PVC strip between the steel plates. The large plate is located on the Mounting rail front, the smaller plate located on the back.
  - Depending on the selected materials you encounter either the rivets or screw the screws in the PVC strips, so that the panels are firmly attached to the strip.  
For thicker PVC strips, it may happen that you have to pre-drill the holes in the strip prior to assembly.
  - To get a 40% overlap, leave after 1st suspended strips 3 hooks free and depend on the next strip. The 3rd strip hanging over the 3 remained free hooks. Repeat this procedure until the end of the stainless steel rail.
  - To get a 80% overlap, leave after 1st suspended strip 1 hook free and depend on the next strip. The 3rd strip hanging over the remaining free hook. Repeat this procedure until the end of the stainless steel rail.
  - Then you can cut the bottom of the strip with a sharp knife to the desired length.

It is not always possible to achieve the desired overlap, this depends on the length of the mounting rail.